

Installation Kits

VOLVO

V03135B

Volvo Upper Dash Kit for 200 Series. Fits 1973-93 Volvo.

1973-93
Volvo



V001B
1989-up
Volvo
Harness.



V041461B

Volvo Application Specific DIN Mount Kit. Fits select vehicles 1983-92.

1983-92
Volvo



V000B
1981-up
Volvo
Harness.



V001B
1989-up
Volvo
Harness.



V04148B

2001 Volvo S80 Kit. Fits vehicles 2001-06. Color Matched

2001-06
Volvo S80



V003B
2000-up
Volvo
Harness.



V04149B

Volvo Kit. Fits vehicles 2001-04. Color Matched

2001-04 Volvo
S60, V70
Cross Country



V003B
2000-up
Volvo
Harness.



800.621.3695 ext 3

tech support

800.350.0687

fax orders

Installation Kits

VOLVO

VO4150B

Volvo XC90 DIN w/Pocket
Installation Kit. Fits vehicles
2003-up.

**2003-up Volvo
XC90**



V003B
2000-up
Volvo
Harness.



0 33991 01393 3

VO4152B

Volvo S60 & V70 DIN w/Pocket
Installation Kit. Fits vehicles
2005-06.

**2005-06 Volvo
S60
V70**



V003B
2000-up
Volvo
Harness.



0 33991 01394 0

800.363.4490 ext 1

sales hot line

www.scosche.com

SCOSCHE[®]